



Tubular Soil Sampler with Step - 36 Inch (12 inch deep sample depth)



The Turf-Tec Tubular Soil Sampler extracts a core sample 12 inches deep by 3/4 inches wide. Durable, all welded stainless steel design is made in the USA and is not a cheap import. The Turf-Tec Tubular Soil Sampler 36" with step is a stainless steel sampler that has a step on handle for easy insertion into the soil. Stainless design allows for laboratory analysis of clean soil samples.

The Tubular Soil Sampler is excellent for examining the soil for deep analysis. The specially designed cutting tip is ideal for turfgrass rootzones. Tubular Soil Sampler 36" with step can also be used for collecting soil samples for laboratory analysis. It is also useful in determining root depth and moisture content. No more bending over to take soil samples.

The Turf-Tec 36-inch Tubular Soil Sampler extracts a sample 12 Inches deep soil sample by 3/4 inches wide.

Instructions

1. Insert Tubular Soil Sampler 36" with step into soil by putting foot on step and holding handle.
2. Do not use excessive force to drive sampler into ground.
3. Twist sampler 1/2 turn and remove from ground.
4. Inspect soil sample.
5. Sampler should be cleaned with water and mild soap before storing.

TSS2-12-S : Tubular Soil Sampler (Stainless Steel) - 1 Inch Diameter x 36 Inch Tall with Step (12 inch deep sample)

LIMITED WARRANTY OF TURF-TEC INTERNATIONAL PRODUCTS

Turfgrass Products Corporation - dba - Turf-Tec International ("Seller") warrants to the final purchaser, that all Turf-Tec International tools will be free from defects in material or workmanship for a period of one year from date of purchase. SELLER'S SOLE OBLIGATION AND YOUR EXCLUSIVE REMEDY under this Limited Warranty and, to the extent permitted by law, any warranty or condition implied by law, shall be the repair or replacement of parts, without charge, which are defective in material or workmanship and which have not been misused, carelessly handled, or improperly repaired by persons other than Turf-Tec International. To make a claim under this Limited Warranty, you must return the complete tool, transportation prepaid, to Turf-Tec International after contacting Turf-Tec International and receiving a return authorization number. Please include a dated proof of purchase with your tool.

ANY IMPLIED WARRANTIES SHALL BE LIMITED IN DURATION TO ONE YEAR FROM DATE OF PURCHASE. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO LIABILITY FOR LOSS OF PROFITS) ARISING FROM THE SALE OR USE OF THIS PRODUCT.

Hold Harmless Agreement

The seller shall protect, defend, indemnify and hold the purchaser and their respective assigns and their attorneys, accountants, employees, officers and directors harmless from and against all losses, costs, liabilities, claims, damages and expenses of every kind and character, as incurred, resulting from or relating to or arising out of the inaccuracy of results, injury of user, injury of sports participant, turfgrass loss, warranty, covenant or any agreement made by the seller in this agreement.