

65B. Turfchek II - Rough Grass Height Cut Gauge

Order #: HGROUGH-G

Price: \$ 25.00



The Turfchek II is a height of cut gauge designed for taller grass to determine the actual mowing height, right in the field.

The unit is made of high impact plastic and can tell grass height in 1/4 inch increments from 1/2 inch to 2 1/2 inch and then 1/2 inch increments from 2 1/2 inch to 5 1/2 inches tall. The Millimeter side of the Turfchek II shows height of cut in 6 millimeter increments from 6 mm to 60 mm inch and then 12 mm increments from 60 mm to 132 millimeters tall.

67A. The Spot Divot Sand Topdresser

Order #: SPOT1-G

Price: 180.00



The Spot Divot Sand Topdresser allows dry sand to be applied to divots quickly and easily with a press of the handle. Simply put the tool over the divot press down and sand is deposited in the depression. The longer you hold the tool down, the more sand is deposited.

Filling divots allows quicker recovery of playing surfaces and smoother infields. Also The Spot Divot Sand Topdresser can be filled with a mixture of dry sand, fertilizer and seed to speed the divot healing process even more.

70. Turf-Tec Toma Shear Strength Tester

Order #: TShear1-M

Price: \$ 250.00



The new Turf-Tec Toma Shear Strength Tester is a specially designed tool to test the stability of athletic field turfgrass root systems. Simply insert the tool into the turf push down on the top and pull the torque tool until the turf starts to tear. It is ideal to test newly sodded area to see if they are ready for play.

The Turf-Tec Toma Shear Strength Tester also tests the type and depth of cleats that will perform best in your particular turfgrass root system and environment. Simply insert three cleats in the bottom of the tool, press down into the turf and twist torque wrench until any slippage is detected then read the scale. You can compare fields before tournaments or games to determine the proper type of cleats that the players should wear for that field on that day.

DIAGNOSTIC MANAGEMENT PRODUCTS

71. Turf-Tec Diagnostic Kit with hard case

Order #: DKIT1-M

Price: \$ 999.00



The Turf-Tec Diagnostic kit comes with the following items:

MPS1-S - Mascaro Profile Sampler (Full Size)

MS1-W (Short) - Turf-Tec Moisture Sensor - Short Model

PN1-S - Turf-Tec Penetrometer - Full size detachable unit

TSS3-S - 1 Pocket Tubular Soil Sampler 1/2" X 8 1/2 inches.

DPT1-S (F or C) - Digital Pocket Thermometer

IR1-S - Infrared Thermometer with Laser

TSDL5-N - Turf Stress Detection Glasses

All housed in a protective hard case that closes to (27 X 16 X 10 inches)

68. Turf-Tec Tubular Turf Plugger

Order #: TTP1-M

Price: \$ 180.00

69. Plugger Replacement Blade

Order #: TTPB1-M

Price: \$ 45.00



The Tubular Turf Plugger removes grass plugs 2-3/8 inches wide by 2-1/2 inches deep. The hollow handle fills up with 20 plugs, and the plugs are simply ejected out the top by turning unit upside down. Cutter blade is case-hardened steel and is replaceable.

This tool is ideal for filling in thin or dead areas, replanting worn areas in front of mounds or goal mouths, plugging out weeds and transplanting and establishing new grass varieties. Studies indicate plug size is ideal for quickest turfgrass establishment. This tool is heavy duty and designed to last a lifetime.

We also offer a smaller 1 1/2 inch diameter plugger as well, Model BMP1-M.