




<b>33B. Acclima SCX Soil Moisture Sensor and irrigation override controller</b> Order # MS-SCX-01 Price \$ \$129.00	
	<p>The SCX works with your existing irrigation timer, incorporating cutting edge moisture sensing technology to allow your irrigation system to come on only when the soil moisture reaches a level pre-determined by you. The SCX Upgrade Kit converts nearly any timer to run on soil moisture, includes one digital TDT moisture sensor and irrigation override controller.</p> <p>It also includes a Sensor Bypass mode. The weatherproof cabinet is suitable for outdoor installation and is excellent for areas around clubhouses, plant beds or any other turfgrass area. There are also commercial units available for 6 zones, 6 sensor capacity, 12 zones, 12 sensor capacity, 24 zone, 24 sensor capacity and 36 zones, 36 sensor capacities. <a href="#">See website for details.</a></p>
<b>37. Turf-Tec Precipitation / Uniformity Gauge</b> Order #: PUGS2-W Price: \$ 225.00	
	<p>This set of 20 calibrated gauges will indicate how much water each sprinkler head is applying as well as showing the uniformity of the coverage and if any areas are being missed.</p> <p>Simply set out the gauges between the sprinkler heads and run your irrigation cycle for 15 minutes. Precipitation and Uniformity Gauges can be set up in a head to head layout or in a grid pattern.</p> <p>Sold in a set of 16 large gauges and 4 small gauges for a total of 20 gauges and 20 stainless steel support spikes. Gauges are calibrated in 10th of an inch and millimeters.</p>
<b>38. Wireless Rain Gauge with Outdoor Thermometer and 9-day Memory</b> Order # ROM3-W Price \$ 89.00	
	<p>Turf-Tec Wireless Rain Gauge is wireless and includes a 9-day memory function plus an indoor/outdoor temperature. This electronic rain gauge has a self-tipping bucket that automatically empties after each 4/100th inch (1 mm) of rain.</p> <p>The reading is recorded on a LCD counter which mounted indoors. It is also an Electronic Rain Gauge, Electronic Outdoor Thermometer and an Electronic Indoor Thermometer with memory highest and lowest temperatures. The unit is also 100% frost proof.</p>

	<b>40. Cable Locator</b> Order #: CAL01-M Price: \$ 200.00
<p>The cable locator finds wires underground by attaching a battery-powered sending unit to the cut or lost wire. Next a hand held receiving unit is used to pick up a radio frequency to trace the wire. Wires can be traced up to 1/2 mile and up to 4' underground.</p> <p>Unit will find broken or cut irrigation, electrical or satellite wires as well as any type of insulated wire. Unit also has a continuity tester and an individual wire identification feature.</p>	
<b>41. Trim-Clean Sprinkler Head Trimmer</b> Order #: TCLEAN1-M (Specify size) Price: \$ 199.00	
<b>42. Trim-Clean Replacement blades</b> Order #: TCLEAN-HEAD (Specify size) Price: \$ 80.00	
<p>This new tool is simply inserted over sprinkler heads and the heavy gauge serrated stainless steel blade is rotated to cut grass and stolons around head.</p> <p>Unit has interchangeable heads that allows 5", 6", 7" or 8" inch blades to be attached the heavy-duty handle. Trim Clean is sold with one handle and one cutter blade. Please specify cutter blade size when ordering. One tool will last many, many years of sprinkler head trimming.</p>	
	<b>43. Donut Trimmer Edging Blades (Set of 6)</b> Order #: DTBsize-M (Insert Size) Price (Per Set 6): \$ 170.00
<p>Blades attach on your string trimmer and allow you to trim around sprinkler heads with one pass. They are made to fit right over the sprinkler heads for trimming. Blades come in 6", 7" and 8" diameters.</p> <p>Six blades per package. Mix and match any size you need.</p>	
	<b>36A. SKY-MASTER Wind &amp; Weather Meter</b> Order#: WIND1 Price \$ 175.00
<p>This easy to use, pocket-size weather station features complete wind speed functions, humidity, dew point, altitude, barometric pressure with 16 hour graph, temperature, wind-chill, heat index and includes a severe weather audio alarm.</p> <p>Skymaster is water resistant, floats, threaded for tripod mounting and comes with a lanyard. It is an excellent way to check wind speed before spraying or irrigating turfgrass areas. The unit also closes up into the jack knife style protective case. One year warranty.</p>	