

	<b>68. Turf-Tec Tubular Turf Plugger</b> Order #: TTP1-M Price: \$ 180.00 <b>69. Plugger Replacement Blade</b> Order #: TTPB1-M Price: \$ 50.00
	<p>The Tubular Turf Plugger removes grass plugs 2-3/8 inches wide by 2-1/2 inches deep. The hollow handle fills up with 20 plugs, and the plugs are simply ejected out the top by turning unit upside down. Cutter blade is case-hardened steel and is replaceable. This tool is ideal for filling in thin or dead areas, replanting worn areas in front of mounds or goal mouths, plugging out weeds and transplanting and establishing new grass varieties. Studies indicate plug size is ideal for quickest turfgrass establishment. This tool is heavy duty and designed to last a lifetime.</p> <p>We also offer a smaller 1 1/2 inch diameter plugger as well. Model BMP1-M.</p>

	<b>72. Turf-Tec WeedAway Weed Removal Tool</b> Order #: WEED1-M Price: \$ 59.00 <b>73. Turf-Tec WeedAway Replacement Spikes (Set of 3)</b> Order #: TTWA10-M Price (Set 3): \$ 18.00
	<p>The new Turf-Tec Weed Away is a heavy duty weed removal tool designed to twist weeds out of turfgrass areas. It is made of heavy duty gauge steel and also contains an ejection rod to remove the weed from the tool after popping the weed out of the ground. The Turf-Tec WeedAway tool uses three 1/4 inch steel spikes to twist weeds from turfgrass areas without bending over.</p> <p>Now, for the first time, a really heavy duty weed removal tool designed for the rugged maintenance of everyday use. This tool not only removes the weed, but also twists off the entire root system to prevent re-growth.</p>

<b>75. Turf-Tec Aeri-Forke</b> Order #: AF1-M Price: \$ 90.00	
<p>The Turf-Tec Aeri-Forke is a sturdy, handy tool for aerifying dry spots, and small compacted areas by removing two 1/2 inch cores, 5 inches deep. Aeriforke spoons are also replaceable. It is ideal for spot aerifying wear areas like centers of fields, goal mouths, and bench areas, around sprinkler heads and removing cores in any small area without the need for bringing out the big machine.</p>	

<b>71. Turf-Tec Diagnostic Kit with hard case</b> Order #: DKIT1-M Price: \$ 999.00

<p>Turf-Tec International now offers a complete Diagnostic kit for assessing turfgrass problems. The kit includes our most popular diagnostic tools so you can easily transport the tools from one area to another, remove them from the hard plastic protective case and do your testing. The Turf-Tec Diagnostic Kit is ideal for agronomists, sales representatives, consultants, researchers and anybody on the go. It can be checked as luggage for travel and fits easily in your utility vehicle. Now you can have your own traveling laboratory. Test for layers, compaction, moisture levels, stress, soil temperature, canopy temperature and overall turfgrass health. It is ideal for golf courses, sports fields, lawns, tracks, courts and any turf area.</p> <p><b>The Turf-Tec Diagnostic kit comes with the following items:</b></p> <ul style="list-style-type: none"> <li>MPS1-S - Mascaro Profile Sampler (Full Size)</li> <li>MS1-W (Short) - Turf-Tec Moisture Sensor - Short Model</li> <li>PN1-S - Turf-Tec Penetrometer – Full size detachable unit</li> <li>TSS3-S - 1 Pocket Tubular Soil Sampler 1/2" X 8 1/2 inches.</li> <li>DPT1-S (F or C) - Digital Pocket Thermometer</li> <li>IR1-S - Infrared Thermometer with Laser</li> <li>TSDL5-N - Turf Stress Detection Glasses</li> </ul> <p><b>All housed in a protective hard case that closes to (27 X 16 X 10 Inches)</b></p>

Visit our website for individual product literature on each of our products and instruments and for new product additions.

[WWW.TURF-TEC.COM](http://WWW.TURF-TEC.COM)

We have over 150 pages of photographs, literature and our newsletter, the Turf-Tec Digest. You can also order online and pay by credit card.

Fax (850) 580-4027 Website [WWW.TURF-TEC.COM](http://WWW.TURF-TEC.COM)