



Turfchek II Rough Grass Height Cut Gauge



The Turfchek II is a height of cut gauge designed for taller grass to determine the actual mowing height, right in the field. The unit is made of high impact plastic and can tell grass height in inches or millimeters. Simply push the two outside teeth into the soil until the serrated teeth at the bottom of the unit come in firm contact with the soil. Look at the gauge and you can see the actual cutting height of the grass as well as the quality of cut.

This method will measure the actual height of the turfgrass so you can compare it with mower bench settings.

The inch side of the Turfchek II shows height of cut in 1/4 inch increments from 1/2 inch to 2 1/2 inch and then 1/2 inch increments from 2 1/2 inch to 5 1/2 inches tall.

The millimeter side (Optional) of the Turfchek II shows height of cut in 6 millimeter increments from 6 mm to 60 mm and then 12 mm increments from 60 mm to 132 mm tall.

The "quality" of cut may also be inspected by comparing the turf over the viewing plane of the gauge. It is ideal for inspecting green collars, fairways, intermediate roughs and roughs. It is also ideal for measuring athletic fields, infields and outfields as well as soccer and lacrosse fields.



Turfchek II Inch - Rough Grass Height Cut Gauge - Inch Unit



Turfchek II Metric - Rough Grass Height Cut Gauge (Inches and Millimeter unit - (Millimeter side shown))

Instructions

1. Push the two outside spikes into the soil until the saw teeth bottom out on the soil surface.
2. Once resistance increases, you have inserted the TurfCheck II to the proper depth.
3. Sight along the top of the grass and read scale.

HGROUGH-INCH-G - Turfchek II - Rough Grass Height Cut Gauge Inches Only
HGROUGH-METRIC-G - Turfchek II - Rough Grass Height Cut Gauge Inches and Millimeters



[Also see our Height of Cut Prism Gauge](#)



LIMITED WARRANTY OF TURF-TEC INTERNATIONAL PRODUCTS

Turfgrass Products Corporation - dba - Turf-Tec International ("Seller") warrants to the final purchaser, that all Turf-Tec International tools will be free from defects in material or workmanship for a period of one year from date of purchase. SELLER'S SOLE OBLIGATION AND YOUR EXCLUSIVE REMEDY under this Limited Warranty and, to the extent permitted by law, any warranty or condition implied by law, shall be the repair or replacement of parts, without charge, which are defective in material or workmanship and which have not been misused, carelessly handled, or improperly repaired by persons other than Turf-Tec International. To make a claim under this Limited Warranty, you must return the complete tool, transportation prepaid, to Turf-Tec International after contacting Turf-Tec International and receiving a return authorization number. Please include a dated proof of purchase with your tool.

ANY IMPLIED WARRANTIES SHALL BE LIMITED IN DURATION TO ONE YEAR FROM DATE OF PURCHASE. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO LIABILITY FOR LOSS OF PROFITS) ARISING FROM THE SALE OR USE OF THIS PRODUCT.

Hold Harmless Agreement

The seller shall protect, defend, indemnify and hold the purchaser and their respective assigns and their attorneys, accountants, employees, officers and directors harmless from and against all losses, costs, liabilities, claims, damages and expenses of every kind and character, as incurred, resulting from or relating to or arising out of the inaccuracy of results, injury of user, injury of sports participant, turfgrass loss, warranty, covenant or any agreement made by the seller in this agreement.