



Plug Popper - Soil Sampler with Foot Peg Ejector



The Plug Popper featuring a patented piston design that allows you to take a 1 1/2 inch x 4 inch deep plug with the stainless steel sampling tip. After the plug is removed, simply push down on the ejection foot peg to eject the sample. In addition to soil sampling, the probe can also be used to assist in seedling planting and fertilizer tablet applications. The soil probe is constructed of zinc-coated steel and stainless steel for durability and long life.

Overall Height is 50 inches tall. Take samples without ever bending over!

<p>Simply place the stainless steel tip against the top of the soil.</p>	<p>Place one foot into the stirrup</p>
<p>Withdraw the Plug Popper from the soil.</p>	<p>Grasp the collar of the Piston and push the piston forward with your foot to the tip. The soil sample will POP out.</p>

PLUGPOP-01-M - Plug Popper 1 1/2" diameter x 4 inches deep

Plug Popper - Instructions

(Use Caution—Sharp Point)

Unpack the handle and the tip. Place the plate at the top of the sampling tube against the bottom of the stirrup. Insert bolts from the bottom up so the bolt heads will be facing down when assembled. Bolt the sampling tube to the bottom of the stirrup with the bolts included. The Plug Popper is ready to go.

USE

(Use Caution—Sharp Point—Avoid pinching)

After assembly, place the tip against the top of the soil. Place one foot into the stirrup. Gently apply pressure, pushing the tip into the soil. Withdraw the Plug Popper from the soil. Grasp the collar of the Piston (careful to avoid pinching) and push the piston forward to the tip. The soil sample will **POP** out. In wet, sticky soils a little extra effort may be required—but the piston peg will give you leverage if you work it.

CONGRATULATIONS

You have taken a great core sample easily and without breaking your back.

CARE AND MAINTENANCE

The Plug Popper is made from durable materials. Its life will be prolonged by keeping it out of the weather and treating it with respect. Frequent cleaning and lubrication of the tip and piston with mineral oil is strongly recommended.

The Plug Popper is designed to be soil sampling tool. It can also be used to plug warm season grasses and for other plantings.

LIMITED WARRANTY OF TURF-TEC INTERNATIONAL PRODUCTS

Turfgrass Products Corporation - dba - Turf-Tec International ("Seller") warrants to the final purchaser, that all Turf-Tec International tools will be free from defects in material or workmanship for a period of one year from date of purchase. SELLER'S SOLE OBLIGATION AND YOUR EXCLUSIVE REMEDY under this Limited Warranty and, to the extent permitted by law, any warranty or condition implied by law, shall be the repair or replacement of parts, without charge, which are defective in material or workmanship and which have not been misused, carelessly handled, or improperly repaired by persons other than Turf-Tec International. To make a claim under this Limited Warranty, you must return the complete tool, transportation prepaid, to Turf-Tec International after contacting Turf-Tec International and receiving a return authorization number. Please include a dated proof of purchase with your tool.

ANY IMPLIED WARRANTIES SHALL BE LIMITED IN DURATION TO ONE YEAR FROM DATE OF PURCHASE. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO LIABILITY FOR LOSS OF PROFITS) ARISING FROM THE SALE OR USE OF THIS PRODUCT.

Hold Harmless Agreement

The seller shall protect, defend, indemnify and hold the purchaser and their respective assigns and their attorneys, accountants, employees, officers and directors harmless from and against all losses, costs, liabilities, claims, damages and expenses of every kind and character, as incurred, resulting from or relating to or arising out of the inaccuracy of results, injury of user, injury of sports participant, turfgrass loss, warranty, covenant or any agreement made by the seller in this agreement.