



Miltona 9 Inch Adjustable Depth Hex-Plugger with Powerstroke Handle Instructions

Keep cutting edge sharp!

Touch up the factory edge if necessary before you start.

Assembly

<p>Assemble Cup Cutter Handle to Hex Cutting Head. For mounting PowerStroke™ handle, use the 3 screws that come with the handle, hex bolts & 1/4" hex nuts that come with the Hex Cutting Head.</p>	<p>Attach the three phillips head screws that come in the box with the Powerstroke handle through hex cutter blade and secure handle assembly to top.</p>	<p>Install 3 – 1/4" nuts on screw rods from ejector foot as shown.</p>
<p>Install screw rods from ejector foot through bottom handle plate.. Finally push screw rods through movable handle plate as shown.</p>	<p>Install remaining 3 – 1/4" nuts on screw rods from ejector foot as shown.</p>	<p>Be sure PowerStroke™ handle is clear from ejector foot screws as shown. Be sure the handle aligns parallel with the footpads.</p>

Turf-Tec International

		
<p>Assemble Footpads to Hex Cutting Head at desired depth by using the 4 (1/4" x 1/2") hex bolts. Each hole is located at one-inch increments.</p>	<p>Finished 9 Inch Adjustable Depth Hex-Plugger.</p>	

Instructions

1. Step plugger into turf of area to be repaired by using sufficient force with both feet on plugger footpads.
2. Push cutting blade all the way down into soil until footpad's rest on turf.
3. After each plug is cut, tip plugger on its side. Use the cut off trowel to slice off the excess dirt that protrudes below the cutting blade. Be sure this soil falls back into the plug hole. This procedure will result in uniform depth plugs.
4. Cut an equal number of replacement plugs from a nursery area to fill in the hex holes of the area being repaired. The "damaged" plugs are to be discarded or re-grown in the nursery area hex holes.
5. When repairing small areas, plugs will blend in quicker if you keep their grain running in the same direction as the grain of the surrounding green area.
6. Tamp, top dress and water newly repaired area.
7. If you have a problem with plugs not pulling, try the following:
 - a. Twist plugger slightly back and forth before pulling each plug.
 - b. When sharpening the cutting blade, keep bevel on the inside.
 - c. If the plugs pull out of the damaged area, but not from a nursery area, a sod cutter can be used to undercut a strip of sod to pull the plugs from.

PLUG-HEX-9IN-M - Miltona 9 Inch Adjustable Depth Hex-Plugger with Powerstroke Handle

LIMITED WARRANTY OF TURF-TEC INTERNATIONAL PRODUCTS

Turfgrass Products Corporation - dba - Turf-Tec International ("Seller") warrants to the final purchaser that all Turf-Tec International tools will be free from defects in material or workmanship for a period of one year from date of purchase. SELLER'S SOLE OBLIGATION AND YOUR EXCLUSIVE REMEDY under this Limited Warranty and, to the extent permitted by law, any warranty or condition implied by law, shall be the repair or replacement of parts, without charge, which are defective in material or workmanship and which have not been misused, carelessly handled, or improperly repaired by persons other than Turf-Tec International. To make a claim under this Limited Warranty, you must return the complete tool, transportation prepaid, to Turf-Tec International after contacting Turf-Tec International and receiving a return authorization number. Please include a dated proof of purchase with your tool.

ANY IMPLIED WARRANTIES SHALL BE LIMITED IN DURATION TO ONE YEAR FROM DATE OF PURCHASE. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO LIABILITY FOR LOSS OF PROFITS) ARISING FROM THE SALE OR USE OF THIS PRODUCT.

Hold Harmless Agreement

The seller shall protect, defend, indemnify and hold the purchaser and their respective assigns and their attorneys, accountants, employees, officers and directors harmless from and against all losses, costs, liabilities, claims, damages and expenses of every kind and character, as incurred, resulting from or relating to or arising out of the inaccuracy of results, injury of user, injury of sports participant, turfgrass loss, warranty, covenant or any agreement made by the seller in this agreement.